

CURB INLET SCREEN INSTALLATION INSTRUCTIONS

Enclosed for installation: galvanized or stainless-steel fixtures, zip ties, and a curb inlet screen(s). For each fixture there will be one zip tie. The number of screws and zip ties will vary depending on the number and size of the curb inlet screens ordered (extras provided).

1. Using a drill and a 1 ½ inch screw, install the galvanized or stainless-steel fixtures into the concrete gutter pan. Fixture spacing is one fixture approximately every two to three feet.
2. Place a zip tie through the upright holes of the fixture.
3. Place Curb Inlet Screen in front of the fixture with the larger holes at the top and the smaller holes at the bottom.
4. Put the two ends of the zip ties through two different sets of holes in the Inlet Curb Screen.
5. Connect the two ends of the zip tie and loosely tighten.
6. Continue to connect the ends of the zip tie for each angle bracket and loosely tighten.
7. Once all zip ties have been loosely tightened go back and tighten the zip ties completely.
8. Cut the excess ends off the zip ties for a clean, finished look.

